



Tutorials

Highlights

Settings

Sign Out

(http://community.safaribooksonline.com/)

Settings

Sign Out

Feedback (http://community.safa



# Storing data in the Environment object


The Environment global object is one of UFT's reserved objects and it can be used to store and retrieve both runtime and design-time data.




### How to do it...

Proceed with the following steps:

 To store a parameter at design time, navigate to File | Settings from the UFT menu and then select Environment. From the Variable type list box, select User-defined, as shown in the following screenshot:



Click on the + button on the right of your Environment window.
 The Add New Environment Parameter window will open. Enter the new parameter's (variable) name and value:



 Click on the OK button to approve. You will notice that the newly created variable, with its value, now appears on the list. You should pay attention to the Type column, in which it indicates that the variable we just created is Internal:

What does it mean? A user-defined variable is Internal when we define it through the UFT GUI. It becomes External when either we export the

variables to an XML file or define them directly in such a file and later, load the file with the variables and values to the test.

#### How it works...

Definitions of the types of variable classifications are as follows:

- Internal variables: When you open an existing test, which has an Internal variable defined, these will be loaded automatically.
   Changes made to their values during the run session will not be saved. In this sense, the values given to Internal variables using the GUI can be referred to as default values.
- External variables: When you open an existing test, which has its
  user-defined variables loaded from an external XML file, these will
  be loaded automatically. Their values cannot be changed during
  the run session. In this sense, the values given to External
  variables can be referred to as constant values.

## There's more...


We can also store a value to an Environment variable dynamically from the code. Such a variable will have global scope but will be accessible during runtime only. This means that you will not see it in the list of Internal variables, as shown in this recipe. The procedure is equivalent to using the default add method of the Scripting. Dictionary object, as shown in the following line of code:

Environment("MyEnvParam") = "MyEnvValue"

## See also

Refer to an article by Yaron Assa at http://www.advancedqtp.com/reservedobjects-as-an-env-objectreplacement (http://www.advancedqtp.com/reservedobjects-as-an-env-object-replacemen







Sign Out © 2015 Safari. Terms of Service / Privacy Policy